

# Miniîncărcător **SUNWARD SWL4538**

Manual de operare și întreținere

# UTILBEN

0733 040 000

[contact@utilben.ro](mailto:contact@utilben.ro)

[www.utilben.ro](http://www.utilben.ro)

**Da,  
rezolvăm.**



## Cluj

Bulevardul Muncii, nr. 36  
Cluj-Napoca

## Cluj

Strada Transilvaniei, nr. 446  
Baciu

## București

Strada Ithaca FN  
(Autostrada București-Pitești, km 23)  
Giurgiu

## Iași

Transagropolis, nr. 4  
Lețcani

**OIL AND COOLANT AT CORRESPONDING ENVIRONMENTAL TEMPERATURE**

	AMBIENT TEMPERATURE										SPECIFIED CAPACITY	SUPPLEMENTARY CAPACITY
	-22	-4	14	3					104	°F		
	-30	-20	-10	0	10	2				°C		
ENGINE OIL												
HYDRAULIC OIL												
BUTTER												
COOLANT												

**■ NOTE**
**Engine Oil :**

- Refer to the following table for the suitable American Petroleum Institute (API) classification of engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the Fuel Type Used : (Low Sulfur, Ultra Low Sulfur or High Sulfur Fuels).

Fuel Type	Engine oil classification (API classification)	
	Engines with non-EGR Engines with internal EGR	Engines with external EGR
High Sulfur Fuel [0.05 % (500 ppm) ≤ Sulfur Content < 0.50 % (5000 ppm)]	<b>CF</b> (If the "CF-4, CG-4, CH-4, or CI-4" engine oil is used with a high-sulfur fuel, change the engine oil at shorter intervals. (approximately half))	–
Low Sulfur Fuel [Sulfur Content < 0.05 % (500 ppm)] or Ultra Low Sulfur Fuel [Sulfur Content < 0.0015 % (15 ppm)]	<b>CF, CF-4, CG-4, CH-4 or CI-4</b>	<b>CF or CI-4</b> (Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines.)

EGR : Exhaust Gas Re-circulation

W1024941

- CJ-4** classification oil is intended for use in engines equipped with DPF (Diesel Particulate Filter) and is **Not Recommended** for use in Kubota E3 specification engines.
- Oil used in the engine should have API classification and Proper SAE Engine Oil Viscosity according to the ambient temperatures where the engine is operated.
- With strict emission control regulations now in effect, the CF-4 and CG-4 engine oils have been developed for use with low sulfur fuels, for On-Highway vehicle engines. When a Non-Road engine operates on high sulfur fuel, it is advisable to use a "CF or better" classification engine oil with a high Total Base Number (a minimum TBN of 10 is recommended).

**Fuel :**

- Cetane Rating** : The minimum recommended Fuel Cetane Rating is 45. A cetane rating greater than 50 is preferred, especially for ambient temperatures below –20 °C (–4 °F) or elevations above 1500 m (5000 ft).
- Diesel Fuel Specification Type and Sulfur Content % (ppm) used**, must be compliant with all applicable emission regulations for the area in which the engine is operated.
- Use of diesel fuel with sulfur content less than 0.10 % (1000 ppm) is strongly recommended.
- If high-sulfur fuel (sulfur content 0.50 % (5000 ppm) to 1.0 % (10000 ppm)) is used as a diesel fuel, change the engine oil and oil filter at shorter intervals. (approximately half)
- DO NOT USE** Fuels that have sulfur content greater than 1.0 % (10000 ppm).
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87)
- Since KUBOTA diesel engines of less than 56 kW (75 hp) utilize EPA Tier 4 and Interim Tier 4 standards, the use of low sulfur fuel or ultra low sulfur fuel is mandatory for these engines, when operated in US EPA regulated areas. Therefore, please use No.2-D S500 or S15 diesel fuel as an alternative to No.2-D, and use No.1-D S500 or S15 diesel fuel as an alternative to No.1-D for ambient temperatures below –10 °C (14 °F).

1) SAE : Society of Automotive Engineers

2) EN : European Norm

3) ASTM : American Society of Testing and Materials

4) US EPA : United States Environmental Protection Agency

5) No.1-D or No.2-D, S500 : Low Sulfur Diesel (LSD) less than 500 ppm or 0.05 wt.%

No.1-D or No.2-D, S15 : Ultra Low Sulfur Diesel (ULSD) 15 ppm or 0.0015 wt.%

**CAPACITIES**

<i>ITEMS</i>	<i>CAPACITY (Litre)</i>
Model	SWL4538
Hydraulic oil tank	45
Sprocket oil tank	30
Engine coolant	9
Engine oil	11
<b>Fuel tank</b>	<b>85</b>

**CODIFICATION OF THE MAIN CHANGED PART**

The following table shows the codification of the parts need changing frequently.


<b>SWL4538</b>		
<b>PART</b>	<b>SUPPLIER</b>	<b>CODE</b>
Engine Air Filter (1)	Kubota	750201013571
Engine Air Filter (2)	Kubota	750201013572
Oil-water Separator Filter	Kubota	750201013448
Engine Oil Filter	Kubota	750201013570
Engine Fuel Filter	Kubota	750201013450
Hydraulic Oil Filter	Kai Cen	730403000484

**TORQUE FOR SCREWS**


Unless other specification, tighten the nuts and bolts according to the torques shown in the below table. Tighten the goods by the wrenches with gauge.

<b>Thread Diameter (mm)</b>	<b>Quality 8.8 Torque (Nm)</b>	<b>Quality 10.9 Torque (Nm)</b>
<b>M 6</b>	<b>9~12</b>	<b>13~16</b>
<b>M 8</b>	<b>22~30</b>	<b>30~36</b>
<b>M 10</b>	<b>45~59</b>	<b>65~78</b>
<b>M 12</b>	<b>78~104</b>	<b>110~130</b>
<b>M 14</b>	<b>124~165</b>	<b>180~210</b>
<b>M 16</b>	<b>193~257</b>	<b>280~330</b>
<b>M 18</b>	<b>264~354</b>	<b>380~450</b>
<b>M 20</b>	<b>376~502</b>	<b>540~650</b>
<b>M 22</b>	<b>512~683</b>	<b>740~880</b>
<b>M 24</b>	<b>651~868</b>	<b>940~1120</b>
<b>M 27</b>	<b>952~1269</b>	<b>1400~1650</b>
<b>M 30</b>	<b>1293~1723</b>	<b>1700~2000</b>

## LUBRICATION POINTS



▲ Check and clean.  
 □ Check and fill up  
 ○ Replace



### Attention

#### Fuel and Lubricant Chart

Item	Description	Maintenance Interval (hours)						Oil Symbol	Maintenance points
		10	100	250	500	1000	2000		
1	Quick hitch	□						PBL	2
2	Working device pins	□						PGL	12
3	Sprocket wheel box	□			□			EO	2
4	Panel and indicator lights	▲							1
5	Hydraulic oil return filter				○				1
6	Fuel level	□						DF	1
7	Coolant	□					○		1
8	Radiator	□							1
9	V belt tension	□							1
10	Engine oil level	□			○			EO	1
11	Hydraulic oil level	□				○		HO	1
12	Oil and water separator	▲							1
13	Engine oil filter				○				1
14	Fuel filter				○				1
15	Air filter		▲			○			1
16	Accumulator(electrolyte)	□							1

**Attention:**

- Oil symbol  
EQ: Engine oil SAE#CF-4/SH15W-40  
GO: Gear oil SAE#15W140GL-5  
HO: Hydraulic oil ISO VG46(for cold)or VG68(for warm)  
PGL: Grease NLGI#2  
DF: Diesel oil  
Coolant: 50/50 water and antifreeze
- Refer to manual book to use hydraulic oil and gear oil.
- Stop engine when fill up.
- Don't open the cover or oil plug when coolant or oil temperature high, beware of scald.
- Open covers slowly to release pressure.
- Please refer to maintenance book for other details.

**Remarks:**

It must check and maintain following parts for the first 50 hours and every 250 hours operation.

- Engine set bolt.
- Hydraulic pump set bolt.
- Travel motor set bolt.
- Tyre set bolt.
- Axle bolt.
- Other bolts for important parts.

**MAINTENANCE PLAN**

TASKS	BS	50	100	250	500	1000	2000	WR
5.5.1.1 CHECKING ENGINE OIL LEVEL	<b>X</b>							
5.5.1.2 CHECKING ENGINE COOLANT LEVEL	<b>X</b>							
5.5.1.3 CHECKING FUEL LEVEL	<b>X</b>							
5.5.1.4 CHECKING HYDRAULIC OIL LEVEL	<b>X</b>							
5.5.1.5 CHECKING THE ELECTRIC CABLES	<b>X</b>							
5.5.1.6 CHECKING THE TRACK	<b>X</b>							
5.5.1.7 CHECKING THE SEAT BELT	<b>X</b>							
5.5.1.8 CHECKING THE LEAKING OF OIL	<b>X</b>							
5.5.1.9 CHECKING THE QUICK COUPLER	<b>X</b>							
5.5.1.10 CHECKING THE WATER AND SEDIMENTS SEPARATOR	<b>X</b>							
5.5.2.1 CHECKING THE COOLER PIPES		<b>X</b>						
5.5.2.2 CHECKING THE COOLANT LEVEL		<b>X</b>						

5.5.2.3 CREASING THE PINS OF BOOM AND CYLINDERS		<b>X</b>						
5.5.2.4 CHECKING THE WHEEL NUTS DRIVING TORQUE		<b>X</b>						
5.5.3.1 CLEANING THE TERMINALS OF THE BATTERY			<b>X</b>					
5.5.3.2 CLEANING THE OIL TANK'S BREATHER			<b>X</b>					
5.5.3.3 CHECKING THE CYLINDER RODS			<b>X</b>					
5.5.3.4 GREASING ALL OF PINS			<b>X</b>					
5.5.4.1 CHECKING THE TENSION OF THE TRACK				<b>X</b>				
5.5.4.2 ADJUST THE TENSION OF THE TRACK AS NEEDED				<b>X</b>				
5.5.4.3 CHECKING THE FAN BELT				<b>X</b>				
5.5.4.4 CLEANING THE RADIATOR				<b>X</b>				
5.5.4.5 CHANGING THE ENGINE OIL				<b>X</b>				
5.5.4.6 CHANGING THE ENGINE OIL FILTER				<b>X</b>				
5.5.4.7 CHANGING THE FUEL FILTER				<b>X</b>				
5.5.4.8 CHECKING THE NUT TORQUE OF THE HYDRAULIC MOTOR AND DRIVING WHEEL				<b>X</b>				
5.5.5.1 CLEAN THE FUEL-WATER SEPARATOR					<b>X</b>			
5.5.5.2 CLEAN THE TIGHTNESS OF PUMP FIXING SCREWS					<b>X</b>			
5.5.5.3 CHECKING THE BATTERY FLUID LEVEL					<b>X</b>			
5.5.5.4 CHANGING THE HYDRAULIC OIL FILTER					<b>X</b>			
5.5.6.1 CHANGING THE HYDRAULIC OIL AND CLEAN THE SUCTION						<b>X</b>		
5.5.6.2 CHANGING THE AIR FILTER						<b>X</b>		
5.5.6.3 CHECKING THE PRESSURE						<b>X</b>		

OF PUMP AND VALVE								
5.5.6.4 CHANGING THE HYDRAULIC OIL TANK BREATHER						<b>X</b>		
5.5.6.5 CHECKING THE TIGHTNESS OF CYLINDER HEAD SCREW						<b>X</b>		
5.5.6.6 CHECKING THE LOOSENESS OF VALVE						<b>X</b>		
5.5.7.1 CHANGING THE COOLANT							<b>X</b>	
5.5.7.2 CHANGING THE SUCTION FILTER							<b>X</b>	
5.5.7.3 CHECKING THE STARTER AND ALTERNATOR							<b>X</b>	
5.5.8.1 DRAINING THE FUEL TANK								<b>X</b>

## TROUBLE SHOOTING

Trouble	Cause	Solution
<b>Electric system</b>		
Lamps do not work properly even with engine running at high speed	• Fault cables	• Check and repair any loose terminal and connection
Lamps come on intermittently with engine running	• Faulty fan belt tension	• Check the belt tension and adjust it or change it if it is necessary
Charge warning light dose not go out when the engine running, even at high speed	• Faulty alternator • Faulty cables	• Change • Check and repair
Alternator emits abnormal noise	• Faulty alternator	• Change



Trouble	Cause	Solution
Starter does not work with key in START position	<ul style="list-style-type: none"> <li>Faulty cables</li> <li>Battery charge insufficient</li> <li>Faulty main fuse</li> </ul>	<ul style="list-style-type: none"> <li>Check and repair</li> <li>Charge battery</li> <li>Change</li> </ul>
Starter pinion engages and disengages while starting engine	<ul style="list-style-type: none"> <li>Battery charge insufficient</li> </ul>	<ul style="list-style-type: none"> <li>Charge battery</li> </ul>
Engine oil pressure warning light does not come on when engine is stopped	<ul style="list-style-type: none"> <li>Faulty bulb</li> <li>Faulty pressure sensor</li> </ul>	<ul style="list-style-type: none"> <li>Change</li> <li>Change</li> </ul>
Charging warning light does not come on when engine is stopped	<ul style="list-style-type: none"> <li>Faulty bulb</li> <li>Faulty cables</li> </ul>	<ul style="list-style-type: none"> <li>Change</li> <li>Check and repair</li> </ul>
<b>Hydraulic system</b>		
Pumps emit abnormal noise	<ul style="list-style-type: none"> <li>No oil in the tank</li> <li>Faulty pump</li> <li>Hydraulic oil unsuitable for the temperature</li> </ul>	<ul style="list-style-type: none"> <li>Refill oil</li> <li>Check, then repair or change</li> <li>Change the oil</li> </ul>
Equipment moves only at low speed	<ul style="list-style-type: none"> <li>Faulty pump</li> <li>Max. pressure valve setting incorrect, or valves closed due to impurities</li> <li>Dirty drain filter</li> </ul>	<ul style="list-style-type: none"> <li>Check, then repair or change</li> <li>Reset or change</li> <li>Change</li> </ul>
<b>Power system</b>		
Oil pressure warning light remains on even with engine at high speed	<ul style="list-style-type: none"> <li>Oil level too low</li> <li>Oil filter clogged</li> <li>Oil unsuitable for the ambient environment</li> </ul>	<ul style="list-style-type: none"> <li>Refill</li> <li>Change filter</li> <li>Change</li> </ul>
Steam comes out of radiator breather.  The engine coolant temperature indicator reaches overheating range	<ul style="list-style-type: none"> <li>Coolant fluid level low</li> <li>Radiator leakage</li> <li>Fan belt slacked</li> <li>Mud or limestone accumulated in cooling system</li> </ul>	<ul style="list-style-type: none"> <li>Refill</li> <li>Repair</li> <li>Check belt tension and adjust</li> <li>Change coolant and clean cooling system</li> </ul>

Trouble	Cause	Solution
	<ul style="list-style-type: none"> <li>• Radiator fins damaged or closed</li> <li>• Faulty thermostat</li> <li>• Radiator cap loosen or broken</li> <li>• Working at too high altitude</li> </ul>	<ul style="list-style-type: none"> <li>• Repair or clean</li> <li>• Change</li> <li>• Tighten cap or change unit</li> </ul>
Coolant temperature indicator always at the end of right scale	<ul style="list-style-type: none"> <li>• Faulty instrument</li> </ul>	<ul style="list-style-type: none"> <li>• Change</li> </ul>
Coolant temperature indicator always at the end of left scale	<ul style="list-style-type: none"> <li>• Faulty thermostat</li> <li>• Faulty instrument</li> </ul>	<ul style="list-style-type: none"> <li>• Change</li> <li>• Change</li> </ul>
Engine dose not start with starter running	<ul style="list-style-type: none"> <li>• No fuel</li> <li>• Air in fuel system</li> <li>• Compression defect</li> </ul>	<ul style="list-style-type: none"> <li>• Refuel</li> <li>• Bleed system</li> <li>• Adjust valve clearance</li> </ul>
Exhaust gases white or light blue	<ul style="list-style-type: none"> <li>• Too much oil in oil pan</li> <li>• Unsuitable fuel</li> </ul>	<ul style="list-style-type: none"> <li>• Drain some oil</li> <li>• Change with correct fuel</li> </ul>
Exhaust gases occasionally tend to be black	<ul style="list-style-type: none"> <li>• Air cleaner clogged</li> <li>• Faulty injectors</li> <li>• Faulty compression</li> </ul>	<ul style="list-style-type: none"> <li>• Clean or change</li> <li>• Change</li> <li>• Adjust valve clearance</li> </ul>
Combustion noise occasionally resembles a blow	<ul style="list-style-type: none"> <li>• Faulty injectors</li> </ul>	<ul style="list-style-type: none"> <li>• Change</li> </ul>
Abnormal noises (during combustion or in mechanical parts)	<ul style="list-style-type: none"> <li>• Fuel with low cetane rating</li> <li>• Overheating</li> <li>• Exhaust silencer inside damaged</li> <li>• Excessive valve clearance</li> </ul>	<ul style="list-style-type: none"> <li>• Change with correct fuel</li> <li>• Change</li> <li>• Adjust valve clearance</li> </ul>
<b>Transmission system</b>		
Machine moves neither forward nor reverse	<ul style="list-style-type: none"> <li>• Oil level insufficient</li> <li>• Suction filter clogged</li> <li>• Faulty flexible coupler</li> <li>• Max. pressure valves faulty or dirty</li> </ul>	<ul style="list-style-type: none"> <li>• Refill</li> <li>• Change</li> <li>• Change coupler</li> <li>• Clean or change valves</li> </ul>

Trouble	Cause	Solution
	<ul style="list-style-type: none"> <li>Positioning hydraulic connection interrupted</li> <li>Travel motor faulty</li> </ul>	<ul style="list-style-type: none"> <li>Restore connection</li> <li>Repair or change</li> </ul>
Machine moves with delay (with abnormal noise)	<ul style="list-style-type: none"> <li>Oil level too low</li> <li>Presence of foam</li> <li>Suction pipe tightness</li> <li>Suction filter clogged</li> <li>Travel motor faulty</li> </ul>	<ul style="list-style-type: none"> <li>Refill</li> <li>Use the recommended oil</li> <li>Check and eliminate leakage</li> <li>Change</li> <li>Repair or change</li> </ul>
Traction force in the two travel directions is insufficient	<ul style="list-style-type: none"> <li>Endothermic engine does not reach max. speed</li> <li>Auxiliary fuel pump (gear pump) faulty</li> <li>Max. pressure valve setting incorrect</li> <li>Connection to servo control faulty or lever angle incorrect</li> <li>Pressure relief valve setting incorrect</li> <li>Excessive oil temperature</li> <li>Travel motor faulty</li> </ul>	<ul style="list-style-type: none"> <li>Change diesel oil filter and check injection pump</li> <li>Repair or change</li> <li>Reset</li> <li>Restore connection or shift lever to correct position</li> <li>Reset</li> <li>Check oil lever and clean exchanger</li> <li>Repair or change</li> </ul>
Traction force is insufficient in only one direction	<ul style="list-style-type: none"> <li>Endothermic engine strongly overloaded</li> <li>Incorrect setting of the max. pressure valve relevant to that direction</li> </ul>	<ul style="list-style-type: none"> <li>Reduce loads due to lifting</li> <li>Set valve</li> </ul>
Oil overheating	<ul style="list-style-type: none"> <li>Oil level too low</li> <li>Exchanger clogged or dirty</li> <li>Unsuitable oil</li> <li>Suction pipe tightness</li> <li>Setting and operation of the max. pressure valves</li> <li>Travel pump faulty</li> </ul>	<ul style="list-style-type: none"> <li>Refill oil</li> <li>Check and change if necessary</li> <li>Change with correct oil</li> <li>Check and eliminate leakage</li> <li>Check setting, repair or change</li> <li>Repair or change</li> </ul>

Trouble	Cause	Solution
	<ul style="list-style-type: none"> <li>Pressure relief valve with high setting</li> <li>Travel motor faulty</li> </ul>	<ul style="list-style-type: none"> <li>Set valve</li> <li>Repair or change</li> </ul>
Machine dose not reach max. speed	<ul style="list-style-type: none"> <li>Suction filter clogged</li> <li>Endothermic engine dose not reach max. speed</li> <li>Auxiliary pump (gear pump) faulty</li> <li>Pilot pressure insufficient</li> <li>Pressure relief valve setting incorrect</li> </ul>	<ul style="list-style-type: none"> <li>Change</li> <li>Change diesel oil filter and check injection pump</li> <li>Check, repair or change</li> <li>Set</li> <li>Set to rated value</li> </ul>
Machine decelerates discontinuously	<ul style="list-style-type: none"> <li>Mechanical connection with servo control lever too hard</li> </ul>	<ul style="list-style-type: none"> <li>Check if rotation is smooth</li> </ul>
Machine accelerate slowly	<ul style="list-style-type: none"> <li>Engine power drop</li> <li>Pressure relief valve setting incorrect</li> </ul>	<ul style="list-style-type: none"> <li>Check clogging of fuel filter, injection pump and valves</li> <li>Set to rated value</li> </ul>
Oil leakage from engine propeller shaft and/or pump	<ul style="list-style-type: none"> <li>Sealing rings faulty</li> <li>Counter pressure in pump casing</li> <li>By-pass valve setting too high</li> </ul>	<ul style="list-style-type: none"> <li>Change</li> <li>Drain pipes clogged or damaged</li> <li>Check and restore</li> </ul>
<b>Others</b>		
Fuel completely depleted	<ul style="list-style-type: none"> <li>Fuel runs out of</li> </ul>	<ul style="list-style-type: none"> <li>Refuel and bleed the system before start the engine again</li> </ul>
Battery completely depleted	<ul style="list-style-type: none"> <li>Alternator faulty</li> </ul>	<ul style="list-style-type: none"> <li>Repair or change</li> </ul>
	<ul style="list-style-type: none"> <li>Consume electric power when the engine is stopped</li> </ul>	<ul style="list-style-type: none"> <li>Charge the battery</li> <li>Or start the engine with booster cables</li> </ul>
Machine gets stuck in mud	<ul style="list-style-type: none"> <li>Can not get out by itself</li> </ul>	<ul style="list-style-type: none"> <li>Use a wire rope suitable to remove the machine through the tow hook</li> </ul>